



# **Bonpet Fire Extinguisher BFE2 / BFE6 Manual**

## Instructions for use BFE No. 1-17

#### Safety advices

Read the instructions for use carefully and inform further users of fire extinguishers, too.

The information on the instruction manual is to be respected whenever you supply, install a fire extinguisher and before using it.

### **Safety instructions for user:**

- Users of the fire extinguishers must be informed about the handling of the item and about the risks that may occur during firefighting.
- Keep children away from fire extinguishers.
- Operate the fire extinguisher according to the instructions on label and pictograms.
- When using the fire extinguisher, never spray into the face of humans, keep a minimum distance of 1m when spraying to a human.
- Keep fire extinguishers clean, don't use aggressive detergents, clean only with a damp cloth.
- Keep away from direct sun and sunlight.
- For the fire extinguishers in vehicles always use brackets, fix them carefully so that the item can't move or fall down.
- Do not give the fire extinguisher to third person without correct instruction.
- Working temperature range: see on the extinguisher label
- Nominal operating pressure / filling compound /quantity of propellant: see on the extinguisher label.
- The data indicated on the container label, like working temperature range, nominal operating pressure, max.
  operating pressure (PS), quantity of propellant and extinguishing agent are to be observed absolutely and may in no case be exceeded and / or fallen below.
- Do not use a fire extinguisher for other purposes than for which it is supplied.

These fire extinguishers are pressurized items and they have an operational life of 20 years, in normal environment and stress conditions and in non-corrosive environments. In case of exceeding the limits the life of the extinguisher can be drastically reduced.

#### Safety instructions for service and maintenance:

Only skilled people should open and maintain fire extinguishers.

Use only extinguishing agent and spare parts in accordance with the approval certificate.

Fire extinguishers might be under pressure, do not handle it in a rough way, do not open it by force.

Damaged or corroded containers or valves should be handled only by skilled and authorized people.

No technical modification of the container allowed, e.g. welding etc.

Do not throw a fire extinguisher away. Recycling only through the supplier or authorized organizations.

Maintenance of a fire extinguisher has to be done in fixed time schedules by an "expert", or skilled person following the legal prescriptions.

Instructions for service and maintenance must be strictly followed in accordance with the manufacturer's instruction.